

Sno-Cone Machine Instructions

Safety Precautions

- The Sno-Cone Machine can take ice cubes or blocks of ice broken into pieces approximately 3"-4" in size. The ice will not fit in the shaver if the pieces are too large.
- The design of the shaving chute automatically draws the ice against the blade. There is no need for manual effort.
- Only plug rented sno cone machine into a grounded outlet of appropriate volts and amps.
- Keep fingers and hands away from shaving unit of rented sno cone machine when motor is running.
- Insert only ice into the rented sno cone machine's ice-crushing compartment.

Set up

- Place the rented sno cone machine on a stable, level surface, such as a table or counter.
- Make sure to set up the sno cone machine near a grounded, electrical source so that you will not need to use an extension cord, unless approved by the machine's Manufacturer.

Operation

1. Make sure to put the drain hole over a bucket or other area that can accept any draining liquid from the machine. Melted ices and condensation will release through the drain.
2. Plug in and turn on the sno cone machine.
3. Lift the sno cone machine's handle and fill the shaver body, also known as the gooseneck or hopper, about an inch from its top with 3-to-4 inch ice cubes.
4. Push the pusher handle down against the ice in the chute. Apply firm and even pressure to make the best sno (too much pressure will result in sno that is coarse; too little pressure will make the sno mushy).
5. Scoop ice into the sno cone container and pump an amount of flavored syrup correct for the container's size onto the ice.
6. When finished using the rented sno cone machine, turn off switches.

Cleaning

1. Wipe all water and syrup off the outside of the cabinet. Do not wash or immerse in water.
2. Clean the syrup bottles and ladle with warm water only. Please do not use soap, all items will be sanitized upon return.